

ArubaOS-Switch REST API and JSON Schema Reference Guide 16.04



Part Number: 5200-3139
Published: September 2017
Edition: 1

Notices

The information contained herein is subject to change without notice. The only warranties for Hewlett Packard Enterprise products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. Hewlett Packard Enterprise shall not be liable for technical or editorial errors or omissions contained herein.

Confidential computer software. Valid license from Hewlett Packard Enterprise required for possession, use, or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

Links to third-party websites take you outside the Hewlett Packard Enterprise website. Hewlett Packard Enterprise has no control over and is not responsible for information outside the Hewlett Packard Enterprise website.

Acknowledgments

Intel[®], Itanium[®], Pentium[®], Intel Inside[®], and the Intel Inside logo are trademarks of Intel Corporation in the United States and other countries.

Microsoft[®] and Windows[®] are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe[®] and Acrobat[®] are trademarks of Adobe Systems Incorporated.

Java[®] and Oracle[®] are registered trademarks of Oracle and/or its affiliates.

UNIX[®] is a registered trademark of The Open Group.

Chapter 1 About this guide	6
Applicable products.....	6
Chapter 2 RestAPI	7
Overview REST.....	7
Commands.....	7
rest-interface.....	7
rest-interface session-idle-timeout.....	8
debug rest-interface.....	8
Show commands.....	9
show rest interface.....	9
Restrictions.....	9
Basic RestAPI Workflows.....	9
Use case — login-sessions.....	9
Use case — authentication failure.....	10
Use case — creating a VLAN.....	10
Use case — fetching the VLAN.....	10
Use case — logout of session.....	11
Responses and HTTP status codes returned by RestAPI.....	12
GET Response and HTTP status codes returned by the RestAPI.....	12
POST responses and HTTP status codes returned by RestAPI.....	12
PUT responses and HTTP status codes returned by RestAPI.....	13
DELETE responses and HTTP status codes returned by RestAPI.....	13
Chapter 3 Common element list	14
Service ACL.....	14
Service AllowUnsupportedTransceiver.....	15
Service Banner.....	16
Service Cdp.....	16
Service DebugLog.....	16
Service DeviceManagementUser.....	17
Service Dns.....	17
Service Dot1xSupplicantPort.....	18
Service Fastboot.....	19
Service FileTransfer.....	19
Service Lldp.....	19
Service IpAddressSubnet.....	20
Service Iplcmp.....	21
Service IpRoute.....	21
Service IpSourceInterface.....	22
Service Ping.....	23
Service Port.....	23
Service Qos.....	23
Service RadiusProfile.....	27
Service RadiusServer.....	27
Service RestLoginSessions.....	28
Service RestSessionIdleTimeout.....	29
Service SmartratePort.....	29

Service SNTP.....	30
Service SntpServerDetails.....	30
Service System.....	30
Service TraceRoute.....	32
Service Vlan.....	32
Service VlanPort.....	33

Chapter 4 Wired element list..... 35

Service Accounting.....	35
Service AclPort.....	35
Service AclVlan.....	36
Service Activate.....	37
Service ArubaVpn.....	37
Service Authentication.....	38
Service Authorization.....	39
Service BpsCommand.....	39
Service BpsConfig.....	40
Service CaptivePortal.....	41
Service CliCommand.....	42
Service CliBatchCommand.....	42
Service ConfigurationResetCommand.....	42
Service DeviceProfile.....	42
Service DhcpRelay.....	44
Service DhcpRelayVlan.....	45
Service DhcpServer.....	46
Service DhcpServerPool.....	46
Service Dot1x.....	46
Service Dot1xAuthenticatorPort.....	47
Service Dot1xAuthenticationMethod.....	49
Service Dot1xPortSecurity.....	49
Service Dsnoop.....	50
Service EventLog.....	50
Service EventSubscription.....	50
Service Igmp.....	51
Service IncludeCredentials.....	53
Service IpAuth.....	53
Service IpSlaClearCommand.....	54
Service IpSlaClearResponderStatsCommand.....	54
Service IPSlaConfig.....	55
Service ip-slas.....	56
Service IpSlaResponder.....	57
Service IpSlaResponderStats.....	58
Service LACP.....	58
Service LocatorLedBlink.....	59
Service MacAuthenticationPort.....	59
Service MacAuthentication.....	60
Service MacTable.....	60
Service Module.....	61
Service Mstp.....	61
Service Oobm.....	61
Service Poe.....	62
Service PortMirrorSession.....	62
Service PortRateLimit.....	63
Service PortSecurity.....	64
Service QosPort.....	64

Service QosVlan.....	65
Service RadiusServerGroup.....	66
Service RedundancyManagement.....	66
Service RestVersion.....	66
Service Snmpv3.....	67
Service SnmpServer.....	69
Service SnmpServerCommunities.....	70
Service SnmpServerHosts.....	70
Service SnmpServerMib.....	71
Service SnmpServerResponseSource.....	71
Service SnmpServerTraps.....	72
Service SnmpServerTrapSource.....	72
Service SpanningTree.....	73
Service SwitchConfig.....	73
Service SwitchSystem.....	74
Service Syslog.....	74
Service SyslogEventCriteria.....	74
Service SyslogFilter.....	75
Service TACACSProfile.....	76
Service TAConfig.....	76
Service TftpClient.....	77
Service Transceiver.....	77
Service Trunk.....	78
Service VsfCommand.....	78
Service VsfConfig.....	79
Service WebAuth.....	81
Service WebAuthPort.....	82

Chapter 5 Websites..... 83

Chapter 6 Support and other resources..... 84

Accessing Hewlett Packard Enterprise Support.....	84
Accessing updates.....	84
Customer self repair.....	84
Remote support.....	85
Warranty information.....	85
Regulatory information.....	85
Documentation feedback.....	86

This guide provides information on how to use RestAPI and JSON schema.

Applicable products

This guide applies to these products:

Aruba 2530 Switch Series (J9772A, J9773A, J9774A, J9775A, J9776A, J9777A, J9778A, J9779A, J9780A, J9781A, J9782A, J9783A, J9853A, J9854A, J9855A, J9856A, JL070A)

Aruba 2540 Switch Series (JL354A, JL355A, JL356A, JL357A)

Aruba 2620 Switch Series (J9623A, J9624A, J9625A, J9626A, J9627A)

Aruba 2920 Switch Series (J9726A, J9727A, J9728A, J9729A, J9836A)

Aruba 2930F Switch Series (JL253A, JL254A, JL255A, JL256A, JL258A, JL259A, JL260A, JL261A, JL262A, JL263A, JL264A)

Aruba 2930M Switch Series (JL319A, JL320A, JL321A, JL322A, JL323A, JL324A)

Aruba 3800 Switch Series (J9573A, J9574A, J9575A, J9576A, J9584A)

Aruba 3810 Switch Series (JL071A, JL072A, JL073A, JL074A, JL075A, JL076A)

Aruba 5400R zl2 Switch Series (J9821A, J9822A, J9850A, J9851A, JL001A, JL002A, JL003A, JL095A)

Overview REST

Representational State Transfer (REST) is a software architecture style consisting of guidelines and best practices for creating scalable web services. RESTful systems typically communicate over HTTP using the same verbs (that is, GET, POST, PUT, DELETE) used by web browsers.

The REST server listens for requests from clients on port 80 (HTTP) and port 443 (HTTPS). The REST service context is "/rest" followed by REST version. For example, `http://192.168.1.1/rest/v1.0`. REST requests also may be sent on the HTTPS port (443).



NOTE

- The REST interface is enabled by default.
- Web management or web management SSL must be enabled. If web management is disabled, requests will not be processed, irrespective of the REST interface status.
- REST requests may also be sent to a switch through an OOBM port.

More information

- JSON Schema and REST API documentation for the most recent version of the software:
 - [JSON Schema X.16.01.xxxx](#)
 - [JSON Schema X.16.02.xxxx](#)
 - [JSON Schema X.16.03.xxxx](#)
 - [JSON Schema X.16.04.xxxx](#)

Commands

rest-interface

Syntax

```
rest-interface
```

```
no rest-interface
```

Description

Enables the REST interface.

The `no` form of this command disables the REST interface.



NOTE

Web management or Web management SSL must be enabled to process the REST requests. If Web management is disabled, the REST requests will not be processed even though the REST interface is enabled.

Command context

Required context: `config`

Examples

Enable the REST interface.

```
switch(config)# rest-interface
switch(config)# show rest-interface

REST Interface - Server Configuration

REST Interface           : Enabled
REST Operational Status  : Up
REST Session Idle Timeout : 600 seconds
HTTP Access              : Enabled
HTTPS Access             : Disabled
```

Disable the REST interface.

```
switch(config)# no rest-interface
switch(config)# show rest-interface

REST Interface - Server Configuration
REST Interface           : Disabled
REST Operational Status  : Down
HTTP Access              : Enabled
HTTPS Access             : Disabled
```

rest-interface session-idle-timeout

Syntax

```
rest-interface session-idle-timeout <SECONDS>
```

```
no rest-interface session-idle-timeout
```

Description

Configure session-idle-timeout for the REST interface sessions. The configurable value range is from 120 to 7200 seconds with the default value at 600 seconds.

The `no` version of the command resets the session-idle-timeout to the default value.

Command context

Required context: `config`

debug rest-interface

Syntax

```
debug rest-interface
```

Enables debug logs for the rest-interface.

debug rest-interface

```
HP-2920-48G(config)# debug rest-interface
0000:00:23:14.01 rest tHttpd:Received REST POST request
0000:00:23:14.08 rest tHttpd:(http_state:)http_process_post END
```



```
0000:00:23:14.15 rest tHttpd:REST request redirected to REST server
0000:00:23:14.22 rest tHttpd:Send REST request message to REST control task
0000:00:23:14.30 rest tHttpd:tHttpd is unblocked with necessary cleanup
0000:00:23:14.38 rest mrest_ctrl:Request for parse header
0000:00:23:14.44 rest mrest_ctrl:Request for parse header after method POST
```

Show commands

show rest interface

Syntax

```
show rest interface
```

Description

The REST operational status will be shown as Up only when the REST interface is enabled and either Web management or Web management SSL is enabled. HTTP access is enabled when Web management is enabled. HTTPS access is enabled when Web management SSL is enabled.

Command context

Required context: `operator`

Example

```
switch# show rest-interface
REST Interface - Server Configuration
  REST Interface           : Enabled
  REST Operational Status  : Up
  REST Session Idle Timeout : 600 seconds
  HTTP Access              : Enabled
  HTTPS Access             : Disabled
```

Restrictions

- Rest interface is not supported in FIPS.
- Rest Interface is not supported on ArubaOS 3800 stack switches.

Basic RestAPI Workflows

Use case — login-sessions

If a user is configured on the switch, login request must be posted to the switch for authentication. If user validation is successful, the switch returns a session id as a cookie that will be used for further requests.



Users are able to create a maximum of five REST sessions simultaneously.

```
WorkStation# curl --noproxy 10.100.167.104 -X POST
http://10.100.167.104:80/rest/v1/login-sessions -d '{"userName":"test",
"password":"test"}'
```

Response from the switch when user validation is successful:

```
{
"uri": "/rest/v1/login-sessions", "cookie":
"sessionId=09CG1bRuT5hkCPzI97mmDjpn4uLtsmgkBsAaWUr9h7Gx1kbsiASak1PEyj7Ov3n"
}
```

Use case — authentication failure

The switch will return an error if authentication fails:

```
WorkStation# curl --noproxy 10.100.167.104 -X POST
http://10.100.167.104:80/rest/v1/login-sessions -d '{"userName":"test",
"password":"test"}'
```

Switch response upon failure:

```
{
"message": "Authentication failed."
}
```



- An operator may only use the **GET** method. A manager is supported for all methods.
- Posting a login request is not required and requests may be sent without a cookie if a user name is not configured.

Other failure causes

1. The wrong username/password is sent to create login sessions.
2. The user is configured and REST requests are sent without session id.

Use case — creating a VLAN

Creating VLAN using REST:

```
WorkStation# curl --noproxy 10.100.167.104 --cookie
"sessionId=09CG1bRuT5hkCPzI97mmDjpn4uLtsmgkBsAaWUr9h7Gx1kbsiASak1PEyj7Ov3n" -X
POST
http://10.100.167.104:80/rest/v1/vlans -d '{"vlan_id":5, "name":"VLAN5"}'
```

Response from the Switch:

```
{
  "uri": "/rest/v1/vlans/5",
  "vlan_id": 5,
  "name": "VLAN5",
  "status": "VS_PORT_BASED",
  "type": "VT_STATIC",
  "is_voice_enabled": false,
  "is_jumbo_enabled": false,
  "is_dsnoop_enabled": false
}
```

Use case — fetching the VLAN

Fetching the VLAN details using REST:

```
WorkStation# curl --noproxy 10.100.167.104 --cookie
```

```
"sessionId=09CG1bRuT5hkCPzI97mmDjpn4uLtsmgkBsAaWUr9h7GxlkbsiASak1PEyj7Ov3n" -X GET
http://10.100.167.104:80/rest/v1/vlans
```

Response from the Switch:

```
{
  "collection_result": {
    "total_elements_count": 2,
    "filtered_elements_count": 2
  },
  "vlan_element": [
    {
      "uri": "/rest/v1/vlans/1",
      "vlan_id": 1,
      "name": "DEFAULT_VLAN",
      "status": "VS_PORT_BASED",
      "type": "VT_STATIC",
      "is_voice_enabled": false,
      "is_jumbo_enabled": false,
      "is_dsnoop_enabled": false
    },
    {
      "uri": "/rest/v1/vlans/5",
      "vlan_id": 5,
      "name": "VLAN5",
      "status": "VS_PORT_BASED",
      "type": "VT_STATIC",
      "is_voice_enabled": false,
      "is_jumbo_enabled": false,
      "is_dsnoop_enabled": false
    }
  ]
}
```

Use case — logout of session

Logout of REST session.

```
WorkStation# curl --noproxy 10.100.167.104 --cookie
"sessionId=09CG1bRuT5hkCPzI97mmDjpn4uLtsmgkBsAaWUr9h7GxlkbsiASak1PEyj7Ov3n" -X
DELETE http://10.100.167.104:80/rest/v1/login-sessions
```

The switch will respond with a message similar to: 204 No Content.

```
[root@UbuntuServer5224 ~]# curl --noproxy 192.168.1.1 -v --cookie
"sessionId=8XU2msUzBJbXYClpFyVmaageB4iiRE6C94QsVYIfd3xiHelPjgUraYOx5JjWIUq" -X
DELETE http://192.168.1.1:80/rest/v1/login-sessions
* About to connect() to 192.168.1.1 port 80 (#0)
*   Trying 192.168.1.1... connected
> DELETE /rest/v1/login-sessions HTTP/1.1
> User-Agent: curl/7.22.0 (x86_64-pc-linux-gnu) libcurl/7.22.0 OpenSSL/1.0.1 zlib/
1.2.3.4 libidn/1.23 librtmp/2.3
> Host: 192.168.1.1
> Accept: */*
> Cookie: sessionId=8XU2msUzBJbXYClpFyVmaageB4iiRE6C94QsVYIfd3xiHelPjgUraYOx5JjWIUq
>
< HTTP/1.1 204 No Content
< Server: eHTTP v2.0
```

```

< Connection: keep-alive
< RequestId:
<
* Connection #0 to host 192.168.1.1 left intact
* Closing connection #0
[root@UbuntuServer5224 ~]#

```

Responses and HTTP status codes returned by RestAPI

GET Response and HTTP status codes returned by the RestAPI

Table 1: *GET Response and HTTP status codes*

Response Code	Description
200 OK	Request is successful.
400 Bad request	Request is invalid due to incorrect parameters in the request.
404 Not Found	Request has failed due to non-existent resource.
500 Internal Server Error	Request has failed due to an error in the switch.

POST responses and HTTP status codes returned by RestAPI

Table 2: *POST responses and HTTP status codes*

Response Code	Description
200 OK	Command URI is successful.
201 Created	Command URI is created.
202 Accepted	Command URI is accepted.
204 No Content	No content is returned for command URI.
400 Bad Request	Request has failed due to incorrect parameters in the request.
404 Not Found	Request is failed due to non-existent resource.
405 Method Not Allowed	Request not supported on a resource.
500 Internal Server Error	Request is failed due to an error in the switch.

PUT responses and HTTP status codes returned by RestAPI

Table 3: *PUT responses and HTTP status codes*

Response Code	Description
200 OK	Resource is successful.
400 Bad Request	Failed due to incorrect parameters in the request.
404 Not Found	Failed due to non-existent resource.
405 Method Not Allowed	Not supported on a resource.
500 Internal Server Error	Failed due to an error in the switch.

DELETE responses and HTTP status codes returned by RestAPI

Table 4: *DELETE responses and HTTP status codes*

Response code	Description
204 No Content	Delete on a resource is successful.
400 Bad Request	Invalid DELETE request [some incorrect parameters in the request].
404 Not Found	Request has failed due to non-existent resource.
405 Method Not Allowed	Not supported on a resource.
500 Internal Server Error	Request is failed due to an error in the switch.

Service ACL

HTTP Method	Resource	Request	Response	Description
GET	.../acls	N/A	CommonElementList	Returns the list of ACL elements matching the given query.
POST	.../acls	Acl	Acl	Adds the given ACL to the model.
GET	.../acls/{Acl.id}	N/A	Acl	Returns the ACL matching the given ID.
DELETE	.../acls/{Acl.id}	N/A	N/A	Deletes the ACL with the given ID from the model.
GET	.../acls/{Acl.id}/rules	N/A	CommonElementList	Returns the list of ACL Rule elements matching the given query.
POST	.../acls/{AclRule.acl_id}/rules	AclRule	AclRule	Adds the given ACL Rule to the model.
GET	.../acls/{AclRule.acl_id}/rules/{AclRule.sequence_no}	N/A	AclRule	Returns the ACL Rule matching the given ID.

Table Continued

HTTP Method	Resource	Request	Response	Description
PUT	.../acls/{AclRule.acl_id}/rules/{AclRule.sequence_no}	AclRule	AclRule	Updates the given ACL Rule in the model.
DELETE	.../acls/{AclRule.acl_id}/rules/{AclRule.sequence_no}	N/A	N/A	Deletes the ACL Rule with the given ID from the model.
POST	.../acls/{ResequenceCommand.acl_id}/rules/resequence	ResequenceCommand	Void	Triggers a resequence of ACL Rule elements based on the given parameters.
GET	.../acls/rules	N/A	CommonElementList	Returns the list of ACL Rule elements for all ACLs.

Service AllowUnsupportedTransceiver

HTTP Method	Resource	Request	Response	Description
GET	.../allow_unsupported_transceiver	N/A	N/A	Returns AllowUnsupportedTransceiver system attribute.
PUT	.../allow_unsupported_transceiver	N/A	N/A	Updates AllowUnsupportedTransceiver system attribute.

Service Banner

HTTP Method	Resource	Request	Response	Description
GET	.../banner			
		N/A	Banner	Returns Banner system attributes.
PUT	.../banner			
		Banner	Banner	Updates Banner system attributes.

Service Cdp

HTTP Method	Resource	Request	Response	Description
GET	.../cdp			
		N/A	Cdp	Returns the global CDP configuration data.
GET	.../cdp			
		Cdp	Cdp	Updates the global CDP configuration data.

Service DebugLog

HTTP Method	Resource	Request	Response	Description
POST	.../debug-log/filter			
		DebugLogFilterCommand	DebugLogStats	Triggers the filtering of debug logs based on the given parameters.
GET	.../debug-log/status			
		N/A	DebugLogStats	Returns the status of the debug log filters.



Added attributes “debug_destination_to_enable” and “debug_destination_to_disable” in DebugLogFilterCommand and added attributes “debug_destination” in DebugLogStats.

Service DeviceManagementUser

HTTP Method	Resource	Request	Response	Description
GET	.../management-user			
		N/A	CommonElementList	Returns the list of Management User elements matching the given query.
POST	.../management-user			
		DeviceManagementUser	DeviceManagementUser	Adds the given Management User to the model.
GET	.../management-user/{DeviceManagementUser.type}			
		N/A	DeviceManagementUser	Returns the Management User matching the given ID.
PUT	.../management-user/{DeviceManagementUser.type}			
		DeviceManagementUser	DeviceManagementUser	Updates the given Management User in the model.
DELETE	.../management-user/{DeviceManagementUser.type}			
		N/A	N/A	Deletes the Management User with the given ID from the model.

Service Dns

HTTP Method	Resource	Request	Response	Description
GET	.../dns			
		N/A	Dns	Returns the host system attributes.
PUT	.../dns			
		Dns	Dns	Updates the host system attributes.

Service Dot1xSupplicantPort

HTTP Method	Resource	Request	Response	Description
GET	../dot1x/supplicant			
		N/A	CommonElementList	Returns the list of 802.1X Supplicant Port elements matching the given query.
GET	../dot1x/supplicant/{Dot1xSupplicantPort.port_id}			
		N/A	Dot1xSupplicantPort	Returns the 802.1X Supplicant Port matching the given ID.
GET	../dot1x/supplicant/{Dot1xSupplicantPort.port_id}			
			Dot1xSupplicantPort	Returns the 802.1X Supplicant Port matching the given ID.
PUT	../dot1x/supplicant/{Dot1xSupplicantPort.port_id}			
		Dot1xSupplicantPort	Dot1xSupplicantPort	Updates the given 802.1X Supplicant Port in the model.
POST	../dot1x/supplicant/{Dot1xSupplicantPort.port_id}/clearstats			
		N/A	N/A	Clear statistics of dot1x supplicant based on port id.
POST	../dot1x/supplicant/{Dot1xSupplicantPort.port_id}/initialize			
		N/A	N/A	Initialize of dot1x supplicant based on port id.
GET	../dot1x/supplicant/{Dot1xSupplicantPort.port_id}/stats			
		N/A	Dot1xSupplicantPort	Returns the 802.1X Supplicant statistics matching the given port.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../dot1x/supPLICANT/stats	N/A	CommonElementList	Returns the list of 802.1X SupPLICANT statistics elements matching the given query.

Service Fastboot

HTTP Method	Resource	Request	Response	Description
GET	.../fastboot	N/A	Fastboot	Returns Fastboot system attribute.
PUT	.../fastboot	Fastboot	Fastboot	Updates Fastboot system attribute.

Service FileTransfer

HTTP Method	Resource	Request	Response	Description
POST	.../file-transfer	FileTransferCommand	Void	Triggers a file transfer based on the given parameters.



Added “show_tech_option” and removed parameters “reboot_device_after_download” and “force_firmware_install” in FileTransferCommand . Modified the enum “FileTransferType”.

Service Lldp

HTTP Method	Resource	Request	Response	Description
GET	.../lldp	N/A	Lldp	Get LLDP Global Status.
PUT	.../lldp			

Table Continued

HTTP Method	Resource	Request	Response	Description
		Lldp	Lldp	Enable/Disable LLDP Globally.
GET	.../lldp/local-port			
		N/A	CommonElementList	Retrieve the complete list of LLDP Local Port elements.
GET	.../lldp/local-port/{LldpLocalPort.port_id}			
		N/A	LldpLocalPort	Get LLDP Local Port Configurations.
PUT	.../lldp/local-port/{LldpLocalPort.port_id}			
		LldpLocalPort	LldpLocalPort	Set LLDP Local Port Configurations.

Service IpAddressSubnet

HTTP Method	Resource	Request	Response	Description
GET	.../ipaddresses			
		N/A	CommonElementList	Returns the list of IP Address Subnets elements matching the given query.
GET	.../vlans/{Vlan.vlan_id}/ipaddresses			
		N/A	CommonElementList	Returns IP Address Subnets for the specified VLAN.
POST	.../vlans/{IpAddressSubnet.vlan_id}/ipaddresses			
		IpAddressSubnet	IpAddressSubnet	Adds the given IP Address Subnet in the model.

Table Continued

HTTP Method	Resource	Request	Response	Description
DELETE	.../vlans/{Vlan.vlan_id}/ipaddresses	N/A	N/A	Deletes IP Address Subnets for the specified VLAN.

Service IpIcmp

HTTP Method	Resource	Request	Response	Description
GET	.../ip_icmp	N/A	IpIcmp	Returns IP ICMP attributes.
PUT	.../ip_icmp	IpIcmp	IpIcmp	Updates IP ICMP attributes.

Service IpRoute

HTTP Method	Resource	Request	Response	Description
GET	.../ip-route	N/A	CommonElementList	Returns the list of IP Route elements matching the given query.
POST	.../ip-route	IpRoute	IpRoute	Adds the given IP Route in the model.
GET	.../ip-route/{IpRoute.id}	N/A	IpRoute	Returns the IP Route matching the given ID.
DELETE	.../ip-route/{IpRoute.id}	N/A	N/A	Deletes the IP Route with the given ID from the model.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../ip-route/settings	N/A	IpRouteSettings	Returns the global IP Route settings.
PUT	.../ip-route/settings	IpRouteSettings	IpRouteSettings	Updates the global IP Route settings.

Service IpSourceInterface

HTTP Method	Resource	Request	Response	Description
GET	.../ip_source_interface	N/A	IpSourceInterface	Returns all IP source-interfaces.
GET	.../ip_source_interface/{IpSourceInterface.protocol}	N/A	IpSourceInterface	Returns IP source-interface based on the protocol.
PUT	.../ip_source_interface/{IpSourceInterface.protocol}	IpSourceInterface	IpSourceInterface	Update IP source-interface record for a protocol. <ul style="list-style-type: none"> If both IP address & VLAN ID are null; configuration will be removed based on protocol. If both valid IP address & VLAN ID are given in REST request, IP address will have preference over VLAN ID.

Service Ping

HTTP Method	Resource	Request	Response	Description
POST	.../ping			
		PingCommand	PingCommandResult	Triggers a ping based on the given parameters.

Service Port

Service Port

HTTP Method	Resource	Request	Response	Description
GET	.../ports			
		N/A	CommonElementList	Returns the list of Port elements matching the given query.
GET	.../ports/{Port.id}			
		N/A	Port	Returns the Port matching the given ID.
PUT	.../ports/{Port.id}			
		Port	Port	Updates the given Port in the model.

Service Qos

HTTP Method	Resource	Request	Response	Description
GET	.../qos/dscp-map			
		CommonCollectionQuery	CommonElementList	Returns the list of QoS DSCP Map elements matching the given query.
GET	.../qos/dscp-map/{QosDscpMap.dscp_value}			

Table Continued

HTTP Method	Resource	Request	Response	Description
		QosDscpMap	QosDscpMap	Returns the QoS DSCP Map matching the given ID.
PUT	.../qos/dscp-map/{QosDscpMap.dscp_value}	QosDscpMap	QosDscpMap	Updates the given QoS DSCP Map in the model.
GET	.../qos/policies	CommonCollectionQuery	CommonElementList	Returns the list of QoS Policy elements matching the given query.
POST	.../qos/policies	QosPolicy	QosPolicy	Adds the given QoS Policy to the model.
GET	.../qos/policies/{QosPolicy.id}	QosPolicy	QosPolicy	Returns the QoS Policy matching the given ID.
DELETE	.../qos/policies/{QosPolicy.id}	N/A	N/A	Deletes the QoS Policy with the given ID from the model.
GET	.../qos/policies/{QosPolicy.id}/policy-actions	QosPolicy	CommonElementList	Returns the list of QoS Policy Action elements matching the given query.

Table Continued

HTTP Method	Resource	Request	Response	Description
POST	.../qos/policies/{QosPolicyAction.policy_id}/policy-actions	QosPolicyAction	QosPolicyAction	Adds the given QoS Policy Action to the model.
GET	.../qos/policies/{QosPolicyAction.policy_id}/policy-actions/{QosPolicyAction.sequence_no}	QosPolicyAction	QosPolicyAction	Returns the QoS Policy Action matching the given ID.
PUT	.../qos/policies/{QosPolicyAction.policy_id}/policy-actions/{QosPolicyAction.sequence_no}	QosPolicyAction	QosPolicyAction	Updates the given QoS Policy Action in the model.
DELETE	.../qos/policies/{QosPolicyAction.policy_id}/policy-actions/{QosPolicyAction.sequence_no}	N/A	N/A	Deletes the QoS Policy Action with the given ID from the model.
POST	.../qos/policies/{ResequenceCommand.policy_id}/policy-actions/resequence	ResequenceCommand	Void	Triggers a resequence of QoS Policy Action elements based on the given parameters.
GET	.../qos/traffic-classes	CommonCollectionQuery	CommonElementList	Returns the list of QoS Traffic Class elements matching the given query.
POST	.../qos/traffic-classes			

Table Continued

HTTP Method	Resource	Request	Response	Description
		QoSTrafficClass	QoSTrafficClass	Adds the given QoS Traffic Class to the model.
GET	.../qos/traffic-classes/{QoSTrafficClass.id}	QoSTrafficClass	QoSTrafficClass	Returns the QoS Traffic Class matching the given ID.
DELETE	.../qos/traffic-classes/{QoSTrafficClass.id}	N/A	N/A	Deletes the QoS Traffic Class with the given ID from the model.
GET	.../qos/traffic-classes/{QoSTrafficClass.id}/matches	QoSTrafficClass	CommonElementList	Returns the list of QoS Class Match elements matching the given query.
POST	.../qos/traffic-classes/{QoSClassMatch.traffic_class_id}/matches	QoSClassMatch	QoSClassMatch	Adds the given QoS Class Match to the model.
GET	.../qos/traffic-classes/{QoSClassMatch.traffic_class_id}/matches/{QoSClassMatch.sequence_no}	QoSClassMatch	QoSClassMatch	Returns the QoS Class Match matching the given ID.
PUT	.../qos/traffic-classes/{QoSClassMatch.traffic_class_id}/matches/{QoSClassMatch.sequence_no}	QoSClassMatch	QoSClassMatch	Updates the given QoS Class Match in the model.

Table Continued

HTTP Method	Resource	Request	Response	Description
DELETE	.../qos/traffic-classes/{QosClassMatch.traffic_class_id}/matches/{QosClassMatch.sequence_no}	N/A	N/A	Deletes the QoS Class Match with the given ID from the model.
POST	.../qos/traffic_classes/{ResequeneceCommand.traffic_class_id}/matches/resequence	ResequeneceCommand	Void	Triggers a resequence of QoS Class Match elements based on the given parameters.

Service RadiusProfile

HTTP Method	Resource	Request	Response	Description
GET	.../radius_profile	N/A	RadiusProfile	Returns the RADIUS profile information.
PUT	.../radius_profile	RadiusProfile	RadiusProfile	Updates the given RADIUS profile in the model.



Added parameters “dead_time”, “key”, “dyn_autz_port”, “tracking_uname”, and “is_tracking_enabled” in RadiusProfile.

Removed parameter dot1x_authentication_method from RadiusProfile.

Service RadiusServer

HTTP Method	Resource	Request	Response	Description
GET	.../radius_servers	N/A	CommonElementList	Returns the RADIUS server information.

Table Continued

HTTP Method	Resource	Request	Response	Description
POST	.../radius_servers	RadiusServer	RadiusServer	Create the given RADIUS server in the model.
GET	.../radius_servers/{RadiusServer.radius_server_id}	N/A	RadiusServer	Returns the given RADIUS server information.
PUT	.../radius_servers/{RadiusServer.radius_server_id}	RadiusServer	RadiusServer	Updates the given RADIUS server in the model.
DELETE	.../radius_servers/{RadiusServer.radius_server_id}	N/A	N/A	Deletes the given radius server from the model.



Added Parameters “is_dyn_authorization_enabled”, “time_window_type”, “time_window”, and “is_oobm” included in RadiusServer.

Service RestLoginSessions

HTTP Method	Resource	Request	Response	Description
POST	.../rest/v1/login-sessions	RestLoginSessions	RestLoginSessionsResult	Adds the given Management User to the model.

Table Continued

HTTP Method	Resource	Request	Response	Description
DELETE	.../rest/v1/login-sessions	N/A	N/A	Deletes the Management User with the given ID from the model

Service RestSessionIdleTimeout

HTTP Method	Resource	Request	Response	Description
GET	.../rest/v1/session-idle-timeout	N/A	RestSessionIdleTimeout	Returns the Management User matching the given ID.
PUT	.../rest/v1/session-idle-timeout/{RestSessionIdleTimeout.type}	RestSessionIdleTimeout	RestSessionIdleTimeout	Updates the given Management User in the model.

Service SmartratePort

HTTP Method	Resource	Request	Response	Description
GET	.../smartrate/ports	N/A	CommonElementList	Returns the list of Smartrate Port elements matching the given query.
GET	.../smartrate/ports/{SmartratePort.port_id}	N/A	SmartratePort	Returns the Smartrate Port info and stats matching the given ID.

Service SNTP

HTTP Method	Resource	Request	Response	Description
GET	.../system/sntp			
		N/A	Sntp	Returns SNTP system attributes.
PUT	.../system/sntp			
		Sntp	Sntp	Updates SNTP system attributes.

Service SntpServerDetails

HTTP Method	Resource	Request	Response	Description
GET	.../system/sntp_server			
		N/A	CommonElementList	Returns SNTP server system attributes.
POST	.../system/sntp_server			
		SntpServerDetails	SntpServerDetails	Add SNTP server system attributes.
GET	.../system/sntp_server/{SntpServerDetails.sntp_server_priority}- {SntpServerDetails.sntp_server_address}			
		N/A	SntpServerDetails	Returns SNTP server system attributes.
DELETE	.../system/sntp_server/{SntpServerDetails.sntp_server_priority}- {SntpServerDetails.sntp_server_address}			
		N/A	N/A	Delete SNTP server system attributes.

Service System

HTTP Method	Resource	Request	Response	Description
GET	.../system			
		N/A	SystemAttributes	Returns the host system attributes.

Table Continued

HTTP Method	Resource	Request	Response	Description
PUT	.../system	SystemAttributes	SystemAttributes	Updates the host system attributes.
POST	.../system/reboot	RebootCommand	N/A	Triggers a system reboot based on the given parameters.
GET	.../system/status	N/A	SystemInfoStats	Returns the status of the host system.
GET	.../system/time	N/A	SystemTime	Returns the host system time configuration.
PUT	.../system/time	SystemTime	SystemTime	Updates the host system time configuration.
POST	.../system/time/set-manually	SetSystemDateTimeCommand	N/A	Sets the system date/time based on the given parameters.
GET	.../system/status/cpu	N/A	SystemCpuStats	Returns the CPU status of the host system (no sampling info).
GET	.../system/status/memory	N/A	SystemMemoryStats	Returns the memory status of the host system (no sampling info).
GET	.../system/status/storage	N/A	SystemStorageStats	Returns the memory storage of the host system (no sampling info).

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../system/status/time	N/A	SystemTimeStats	Returns the time status of the host system.
POST	.../system/time/server/swap	ListElementSwapComm and	N/A	Triggers a swap of time server entries based on the given parameters. Effectively, this changes the order on which time servers are contacted.



Attribute "operation_mode" changed to "device_operation_mode" in SystemAttributes.json.

Service TraceRoute

HTTP Method	Resource	Request	Response	Description
POST	.../trace-route	TraceRouteCommand	TraceRouteCommandResult	Triggers a trace route based on the given parameters.

Service Vlan

HTTP Method	Resource	Request	Response	Description
GET	.../vlans	N/A	CommonElementList	Returns the list of VLAN elements matching the given query.
POST	.../vlans	Vlan	Vlan	Adds the given VLAN to the model.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../vlans/{Vlan.vlan_id}	N/A	Vlan	Returns the VLAN matching the given ID.
PUT	.../vlans/{Vlan.vlan_id}	Vlan	Vlan	Updates the given VLAN in the model.
DELETE	.../vlans/{Vlan.vlan_id}	N/A	N/A	Deletes the VLAN with the given ID from the model.



Removed attributes “sql.not_null”: true, “sql.unique”: true from parameter “name” of Vlan schema.

Service VlanPort

HTTP Method	Resource	Request	Response	Description
GET	.../vlans-ports	N/A	CommonElementList	Returns the list of VLAN-Port elements matching the given query.
POST	.../vlans-ports	VlanPort	VlanPort	Adds the given VLAN-Port using the specified mode.
GET	.../vlans-ports/{VlanPort.vlan_id}-{VlanPort.port_id}	N/A	VlanPort	Returns the VLAN-Port matching the given ID.
PUT	.../vlans-ports/{VlanPort.vlan_id}-{VlanPort.port_id}			

Table Continued

HTTP Method	Resource	Request	Response	Description
		VlanPort	VlanPort	Updates the given VLAN-Port using the specified mode.
DELETE	.../vlans-ports/{VlanPort.vlan_id}-{VlanPort.port_id}	N/A	N/A	Deletes the given VLAN-Port assignment from the model.

Service Accounting

HTTP Method	Resource	Request	Response	Description
GET	.../accounting			
		N/A	Accounting	Returns accounting configuration.
PUT	.../accounting			
		Accounting	Accounting	Updates the given accounting configuration to the system.

Service AclPort

HTTP Method	Resource	Request	Response	Description
GET	.../ports-access-groups			
		N/A	WiredElementList	Returns the list of ACL Port Policy elements matching the given query.
POST	.../ports-access-groups			
		AclPortPolicy	AclPortPolicy	Adds the given ACL Port Policy to the model.
DELETE	.../ports-access-groups/{AclPortPolicy.port_id}-{AclPortPolicy.acl_id}-{AclPortPolicy.direction}			
		N/A	N/A	Deletes the ACL Port Policy with the given ID from the model.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../ports-access-groups/{AcIPortPolicy.port_id}-{AcIPortPolicy.acl_id}-{AcIPortPolicy.direction}/stats	N/A	AcIPortPolicyStats	Returns the ACL statistics for given ACL ID, Port, and Direction.

Service AcIvLan

HTTP Method	Resource	Request	Response	Description
GET	.../vlans-access-groups	N/A	WiredElementList	Returns the list of ACL VLAN Policy elements matching the given query.
POST	.../vlans-access-groups	AcIvLanPolicy	AcIvLanPolicy	Adds the given ACL VLAN Policy to the model.
DELETE	.../vlans-access-groups/{AcIvLanPolicy.vlan_id}-{AcIvLanPolicy.acl_id}-{AcIvLanPolicy.direction}	N/A	N/A	Deletes the ACL VLAN Policy with the given ID from the model.
GET	.../vlans-access-groups/{AcIvLanPolicy.vlan_id}-{AcIvLanPolicy.acl_id}-{AcIvLanPolicy.direction}/stats	N/A	AcIvLanPolicyStats	Returns the ACL statistics for given ACL ID, VLAN, and Direction.

Service Activate

HTTP Method	Resource	Request	Response	Description
POST	.../activate			
		ActivateProvisionRequest	ActivateProvisionResult	Enable system provisioning and software update using Aruba Activate.
GET	.../activate/config	N/A	ActivateConfig	Returns Aruba Activate provisioning or software update configuration.
PUT	.../activate/config	ActivateConfig	ActivateConfig	Updates attributes for Aruba Activate provisioning or software update.

Service ArubaVpn

HTTP Method	Resource	Request	Response	Description
GET	.../amp-server			
		N/A	AmpServer	Returns the Amp server IP, group, folder and secret.
PUT	.../amp-server	AmpServer	AmpServer	Configure the Amp Server.
DELETE	.../amp-server			
		N/A	N/A	Deletes the Aruba VPN configuration.
GET	.../aruba-vpn			
		N/A	ArubaVpn	Returns the Aruba VPN type, peer IP address, ToS and TTL value.

Table Continued

HTTP Method	Resource	Request	Response	Description
PUT	.../aruba-vpn	ArubaVpn	ArubaVpn	Configure the Aruba VPN.
DELETE	.../aruba-vpn	N/A	N/A	Deletes the Aruba VPN configuration.

Service Authentication

HTTP Method	Resource	Request	Response	Description
GET	.../authentication	N/A	Authentication	Returns the Authentication Attributes configured on the system.
PUT	.../authentication	Authentication	Authentication	Updates the given authentication configuration to the system.
GET	.../authentication/console	N/A	AuthenticationConsole	Returns console authentication configuration.
PUT	.../authentication/console	AuthenticationConsole	AuthenticationConsole	Updates the given console authentication configuration to the system.
GET	.../authentication/ssh	N/A	AuthenticationSsh	Returns ssh authentication configuration.

Table Continued

HTTP Method	Resource	Request	Response	Description
PUT	.../authentication/ssh	AuthenticationSsh	AuthenticationSsh	Updates the given ssh authentication configuration to the system.

Service Authorization

HTTP Method	Resource	Request	Response	Description
GET	.../authorization	N/A	Authorization	Returns authorization configuration.
PUT	.../authorization	Authorization	Authorization	Updates the given authorization configuration to the system.

Service BpsCommand

HTTP Method	Resource	Request	Response	Description
POST	.../stacking/bps/disable	N/A	N/A	Disable BPS stack.
POST	.../stacking/bps/enable	N/A	N/A	Enable BPS stack.
POST	.../stacking/bps/factory_reset	N/A	N/A	Erase the startup configuration and all knowledge of other stack members.
POST	.../stacking/bps/member/remove	N/A	N/A	Erases the stack member configuration.
POST	.../stacking/bps/member/shutdown			

Table Continued

HTTP Method	Resource	Request	Response	Description
		N/A	N/A	Shut down the specified stack member.
POST	.../stacking/bps/set_stack			
		N/A	N/A	Makes the inactive stack active.

Service BpsConfig

HTTP Method	Resource	Request	Response	Description
GET	.../stacking/bps/info			
		N/A	N/A	Returns the BPS stack information.
PUT	.../stacking/bps/info			
		N/A	N/A	Updates the BPS stack information.
GET	.../stacking/bps/members			
		N/A	N/A	Returns all BPS member configuration.
POST	.../stacking/bps/members			
		N/A	N/A	Adds the BPS member matching the given member ID.
GET	.../stacking/bps/members/{BpsMember.member_id}			
		N/A	N/A	Returns the BPS member configuration matching the given member ID.
PUT	.../stacking/bps/members/{ BpsMember.member_id}			
		N/A	N/A	Updates the BPS member configuration matching the given member ID.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../stacking/bps/members/system_info	N/A	N/A	Returns all BPS member system information.
GET	.../stacking/bps/members/system_info /{ BpsMemberSystemInfo.member_id}	N/A	N/A	Returns the BPS member system information matching the given member ID.
GET	.../stacking/bps/stack_ports	N/A	N/A	Returns all BPS stack ports.
GET	.../stacking/bps/stack_ports/members/{ BpsStackPort.member_id}/stack_port/{ BpsStackPort.stacking_port}	N/A	N/A	Returns the details of the specified stack port of the member matching the given member ID.

Service CaptivePortal

HTTP Method	Resource	Request	Response	Description
GET	.../captive_portal	N/A	CaptivePortal	Returns the global Captive Portal Configuration.
PUT	.../captive_portal	CaptivePortal	CaptivePortal	Updates the global Captive Portal Configuration.

Service CliCommand

HTTP Method	Resource	Request	Response	Description
POST	.../cli			
		N/A	N/A	Cli command interface.

Service CliBatchCommand

HTTP Method	Resource	Request	Response	Description
POST	.../cli_batch			
		N/A	N/A	Cli batch command.
GET	.../cli_batch/status			
		N/A	N/A	Cli batch command status.

Service ConfigurationResetCommand

HTTP Method	Resource	Request	Response	Description
POST	.../system/configuration-reset			
		N/A	N/A	Reset the system configuration.

Service DeviceProfile

HTTP Method	Resource	Request	Response	Description
GET	.../device_identities			
		N/A	N/A	Returns all the device identity configuration.
POST	.../device_identities			
		N/A	N/A	Adds the given device identity configuration to the model.
GET	.../device_identities/{DeviceIdentity.device_name}			

Table Continued

HTTP Method	Resource	Request	Response	Description
		N/A	N/A	Returns the given device identity configuration.
PUT	../device_identities/{DeviceIdentity.device_name}			
		N/A	N/A	Update the given device identity configuration to the model.
DELETE	../device_identities/{DeviceIdentity.device_name}			
		N/A	N/A	Deletes the given device identity configuration.
GET	../device_profiles			
		N/A	N/A	Returns all device profile.
POST	../device_profiles			
		N/A	N/A	Adds the given device profile configuration to the model.
GET	../device_profiles-vlans			
		N/A	N/A	Returns all device profile associations.
POST	../device_profiles-vlans			
		N/A	N/A	Adds the given device profile association to the model.
GET	../device_profiles-vlans/{DeviceProfileVlan.device_profile_name}- {DeviceProfileVlan.tagged_vlan_id}			
		N/A	N/A	Returns the device profile vlan configuration.
DELETE	../device_profiles-vlans/{DeviceProfileVlan.device_profile_name}- {DeviceProfileVlan.tagged_vlan_id}			
		N/A	N/A	Deletes device profile vlans.
GET	../device_profiles/{DeviceProfileConfig.device_profile_name}			

Table Continued

HTTP Method	Resource	Request	Response	Description
PUT	.../device_profiles/{DeviceProfileConfig.device_profile_name}	N/A	N/A	Returns the device profile configuration.
DELETE	.../device_profiles/{DeviceProfileConfig.device_profile_name}	N/A	N/A	Update the given device profile configuration to the model.
GET	.../device_profiles/status	N/A	N/A	Deletes device profile configuration.
GET	.../device_types	N/A	N/A	Returns the device profile status configuration.
GET	.../device_types/{DeviceTypeConfig.device_type}	N/A	N/A	Returns all device type configurations.
PUT	.../device_types/{DeviceTypeConfig.device_type}	N/A	N/A	Returns the device type configuration.
				Update the given device type configuration to the model.



/device_identity added in device_profiles.

Service DhcpRelay

HTTP Method	Resource	Request	Response	Description
GET	.../dhcp-relay			
		N/A	DhcpRelay	Returns the DHCP-Relay global attributes.
PUT	.../dhcp-relay			

Table Continued

HTTP Method	Resource	Request	Response	Description
		DhcpRelay	DhcpRelay	Update the DHCP-Relay global attributes.
GET	.../dhcp-relay/option_82			
		N/A	DhcpRelayOption82	Returns the DHCP Relay Option 82.
PUT	.../dhcp-relay/option_82			
		DhcpRelayOption82	DhcpRelayOption82	Updates the given DHCP Relay Option 82.
GET	.../dhcp/options			
		N/A	DhcpOptions	Returns the status of DHCP Options.
PUT	.../dhcp/options			
		DhcpOptions	DhcpOptions	Updates the status of given DHCP Options.

Service DhcpRelayVlan

HTTP Method	Resource	Request	Response	Description
GET	.../vlans/{DhcpRelayVlan.vlan_id}/dhcp-relay			
		N/A	DhcpRelayVlan	Returns the DHCP Relay VLAN matching the given ID.
PUT	.../vlans/{DhcpRelayVlan.vlan_id}/dhcp-relay			
		DhcpRelayVlan	DhcpRelayVlan	Updates the given DHCP Relay VLAN in the model.

Service DhcpServer

HTTP Method	Resource	Request	Response	Description
GET	.../dhcp-server			
		N/A	DhcpServer	Returns the DHCP-Server.
PUT	.../dhcp-server			
		DhcpServer	DhcpServer	Updates DHCP-Server in the model.

Service DhcpServerPool

HTTP Method	Resource	Request	Response	Description
GET	.../dhcp-server/pools			
		N/A	N/A	Returns DHCP-Server pools.
POST	.../dhcp-server/pools			
		N/A	N/A	Adds the given DHCP-Server pool to the model.
GET	.../dhcp-server/pools/{DhcpServerPool.pool_name}			
		N/A	N/A	Returns the DHCP-Server pool by name.
DELETE	.../dhcp-server/pools/{DhcpServerPool.pool_name}			
		N/A	N/A	Deletes DHCP-Server pool by name.

Service Dot1x

HTTP Method	Resource	Request	Response	Description
GET	.../dot1x			
		N/A	Dot1x	Returns the global 802.1X configuration.

Table Continued

HTTP Method	Resource	Request	Response	Description
PUT	.../dot1x	Dot1x	Dot1x	Updates the global 802.1X configuration.

Service Dot1xAuthenticatorPort

HTTP Method	Resource	Request	Response	Description
GET	.../dot1x/authenticator	N/A	N/A	Returns the list of 802.1X Authenticator Port elements matching the given query.
GET	.../dot1x/authenticator/{Dot1xAuthenticatorPort.port_id}	N/A	N/A	Returns the 802.1X Authenticator Port matching the given ID.
PUT	.../dot1x/authenticator/{Dot1xAuthenticatorPort.port_id}	N/A	N/A	Updates the given 802.1X Authenticator Port in the model.
POST	.../dot1x/authenticator/{Dot1xAuthenticatorPort.port_id}/clearstats	N/A	N/A	Clear statistics of dot1x authenticator based on port id.
GET	.../dot1x/authenticator/{Dot1xAuthenticatorClientStats.port_id}/client_stats	N/A	N/A	Returns the 802.1X Authenticator client session statistics matching the given port.
POST	.../dot1x/authenticator/{Dot1xAuthenticatorPort.port_id}/initialize	N/A	N/A	Initialize of dot1x authenticator based on port id.

Table Continued

HTTP Method	Resource	Request	Response	Description
POST	.../dot1x/authenticator/{Dot1xAuthenticatorPort.port_id}/reauthenticate	N/A	N/A	Initialize of dot1x authenticator based on port id.
GET	.../dot1x/authenticator/{Dot1xAuthenticatorSessionCounters.port_id}/session_counters	N/A	N/A	Returns the 802.1X Authenticator session counters matching the given port.
GET	.../dot1x/authenticator/{Dot1xAuthenticatorStats.port_id}/stats	N/A	N/A	Returns the 802.1X Authenticator statistics matching the given port.
GET	.../dot1x/authenticator/{Dot1xAuthenticatorStatus.port_id}/stats	N/A	N/A	Returns the 802.1X Authenticator status matching the given port.
GET	.../dot1x/authenticator/client_stats	N/A	N/A	Returns the list of 802.1X Authenticator client session statistics elements matching the given query.
GET	.../dot1x/authenticator/session_counters	N/A	N/A	Returns the list of 802.1X Authenticator session counters elements matching the given query.
GET	.../dot1x/authenticator/stats	N/A	N/A	Returns the list of 802.1X Authenticator statistics elements matching the given query.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../dot1x/authenticator/status	N/A	N/A	Returns the list of 802.1X Authenticator status elements matching the given query.

Service Dot1xAuthenticationMethod

HTTP Method	Resource	Request	Response	Description
GET	.../dot1x/authentication_method	N/A	Dot1xAuthenticationMethod	Returns the 802.1X Authentication method details.
PUT	.../dot1x/authentication_method	Dot1xAuthenticationMethod	Dot1xAuthenticationMethod	Updates the given 802.1X Authentication method details.

Service Dot1xPortSecurity

HTTP Method	Resource	Request	Response	Description
GET	.../dot1x/port_security	WiredCollectionQuery	WiredElementList	Returns the list of 802.1X Port Security elements matching the given query.
GET	.../dot1x/port_security/{Dot1xPortSecurity.port_id}	N/A	Dot1xPortSecurity	Returns the 802.1X Port security details matching the given ID.
PUT	.../dot1x/port_security/{Dot1xPortSecurity.port_id}	Dot1xPortSecurity	Dot1xPortSecurity	Updates the given 802.1X Port security in the model.

Service Dsnoop

HTTP Method	Resource	Request	Response	Description
GET	.../dsnoop			
		N/A	Dsnoop	Returns the DHCP-Snooping global attributes.
PUT	.../dsnoop			
		Dsnoop	Dsnoop	Update the DHCP-Snooping global attributes.

Service EventLog

HTTP Method	Resource	Request	Response	Description
Get	.../system-event-log			
		EventLogged	LoggedEventResponseList	Download/Query logged events from system.

Service EventSubscription

HTTP Method	Resource	Request	Response	Description
GET	.../event-subscription			
		N/A	SubscriptionStatusList	Returns the subscription status list.
POST	.../event-subscription			
		SubscriptionRequest	SubscriptionStatus	Subscribe to receive events.
GET	.../event-subscription/{SubscriptionStatus.subscription_id}			
		N/A	SubscriptionStatus	Returns the subscription status.
PUT	.../event-subscription/{SubscriptionStatus.subscription_id}			
		SubscriptionRequest	SubscriptionStatus	Update subscription.

Table Continued

HTTP Method	Resource	Request	Response	Description
DELETE	.../event-subscription/{SubscriptionStatus.subscription_id}	N/A	N/A	Delete subscription.

Service Igmp

HTTP Method	Resource	Request	Response	Description
GET	.../igmp	N/A	Igmp	Returns IGMP global configuration.
PUT	.../igmp	Igmp	Igmp	Updates the IGMP global configuration.
GET	.../igmp/ports	N/A	WiredElementList	Returns the list of IGMP fastlearn Port elements matching the given query.
GET	.../igmp/ports/{IgmpPort.port_id}	N/A	IgmpPort	Returns IGMP port fastlearn details.
PUT	.../igmp/ports/{ <u>file:///C:/Users/reider/Desktop/schema/wired/IgmpPort.json</u> IgmpPort.port_id}	IgmpPort	IgmpPort	Updates the IGMP port fastlearn details..
POST	.../igmp/reload	N/A	N/A	Reset IGMP state on all interfaces.
GET	.../igmp/vlans	N/A	WiredElementList	Returns the list of VLAN IGMP elements matching the given query.
GET	.../igmp/vlans/ports			

Table Continued

HTTP Method	Resource	Request	Response	Description
		N/A	WiredElementList	Returns the list of VLAN IGMP port configuration elements matching the given query.
GET	.../igmp/vlans/static_groups			
		N/A	WiredElementList	Returns the list of VLAN IGMP static groups configuration elements matching the given query.
POST	.../igmp/vlans/static_groups			
		VlanIgmpStaticGroup	VlanIgmpStaticGroup	Creates the given VLAN IGMP static groups configuration in the model.
GET	.../igmp/vlans/static_groups/{Void .id}			
		N/A	VlanIgmpStaticGroup	Returns the VLAN IGMP static group configuration matching the given ID.
DELETE	.../igmp/vlans/static_groups/{Void .id}			
		N/A	N/A	Deletes the VLAN IGMP static group configuration matching the given ID.
GET	.../igmp/vlans/stats			
		N/A	WiredElementList	Returns the list of VLAN IGMP Stats elements matching the given query.
GET	.../vlans/{VlanIgmp.vlan_id}/igmp			
		N/A	VlanIgmp	Returns the VLAN IGMP matching the given ID.
PUT	.../vlans/{VlanIgmp.vlan_id}/igmp			

Table Continued

HTTP Method	Resource	Request	Response	Description
		VlanIgmpp	VlanIgmpp	Updates the given VLAN IGMP in the model.
GET	.../vlans/{VlanIgmppPort.vlan_id}/igmp/ports/{VlanIgmppPort .port_id}			
		N/A	VlanIgmppPort	Returns the VLAN IGMP port configuration matching the given ID.
PUT	.../vlans/{VlanIgmppPort.vlan_id}/igmp/ports/{VlanIgmppPort .port_id}			
		VlanIgmppPort	VlanIgmppPort	Updates the given VLAN IGMP port configuration in the model.
GET	.../vlans/{VlanIgmpp.vlan_id}/igmp/stats			
		N/A	VlanIgmppStats	Returns the VLAN IGMP Stats matching the given ID.

Service IncludeCredentials

HTTP Method	Resource	Request	Response	Description
GET	.../system/include-credentials			
		N/A	IncludeCredentials	Returns the Include-Credentials settings.
PUT	.../system/include-credentials			
		IncludeCredentials	IncludeCredentials	Updates the Include-Credentials settings.

Service IpAuth

HTTP Method	Resource	Request	Response	Description
GET	.../ip_auth			
		WiredCollectionQuery	WiredElementList	Returns the list of IP Auth Configuration matching the given query.

Table Continued

HTTP Method	Resource	Request	Response	Description
POST	.../ip_auth	IpAuth	IpAuth	Adds the given IP Auth Configuration to the system.
DELETE	.../ip_auth/{IpAuth.id}	N/A	Void	Deletes the IP Auth Configuration with the given ID from the model.
GET	.../ip_auth/{IpAuth.id}	N/A	IpAuth	Returns the IP Auth Configuration matching the given ID.

Service IpSlaClearCommand

HTTP Method	Resource	Request	Response	Description
POST	.../ip-slas/{IpSlaConfig.ipsla_id}/clearstats	N/A	N/A	Clears History and Message statistics of ipsla based on IPSLA ID.

Service IpSlaClearResponderStatsCommand

HTTP Method	Resource	Request	Response	Description
POST	.../ipsla_responders/clear_stats/{ IpSlaResponder.responder_type}- { IpSlaResponder.destination_address}-{ IpSlaResponder.destination_port}- { IpSlaResponder.source_address}	N/A	N/A	Clears statistics of ipsla responder based on responder details.

Service IPSlaConfig

HTTP Method	Resource	Request	Response	Description
GET	.../ip-slas	N/A	WiredElementList	Returns the list of IP-SLA elements matching the given query.
POST	.../ip-slas	IpSlaConfig	IpSlaConfig	Adds the given IP-SLA to the model.
GET	.../ip-slas/{ IpSlaConfig.ipsla_id}	N/A	IpSlaConfig	Returns the IP-SLA matching the given ID.
DELETE	.../ip-slas/{ IpSlaConfig .ipsla_id}	N/A	Void	Deletes the IP-SLA with the given ID from the model.
GET	.../ip-slas/{ IpSlaStatus .ipsla_id}/status	N/A	IpSlaStatus	Returns the IP-SLA matching the given ID.
PUT	.../ip-slas/{ IpSlaStatus .ipsla_id}/status	IpSlaStatus	IpSlaStatus	Updates the IP-SLA status matching the given ID.
GET	.../ip-slas/history/{ IpSlaHistory .ipsla_id}	N/A	IpSlaHistory	Returns the IP-SLA history matching the given ID.
GET	.../ip-slas/jitter-voip/aggregated_results/{ IpSlaJitterVoipResults .ipsla_id}	N/A	IpSlaJitterVoipResults	Returns the IP-SLA aggregated results for UDP Jitter/ Jitter-For-Voip for the given ID.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	../ip-slas/jitter-voip/results/{ IpSlaJitterVoipResults .ipsla_id}	N/A	IpSlaJitterVoipResults	Returns the IP-SLA results for UDP Jitter/ Jitter-For-Voip for the given ID.
GET	../ip-slas/stats/{ IpSlaMessageStats .ipsla_id}	N/A	IpSlaMessageStats	Returns the IP-SLA stats matching the given ID.

Service ip-slas

HTTP Method	Resource	Request	Response	Description
GET	...rest/v2/ip-slas	N/A	N/A	Created API to get the list of IP-SLA elements.
POST	... rest/v2/ip-slas	N/A	N/A	API to create an IP-SLA element.
GET	... rest/v2/ip-slas/{IpSlaConfig.ipsla_id}	N/A	N/A	Created API to get details of the IP-SLA matching with the given ID.
DELETE	... rest/v2/ip-slas/{IpSlaConfig.ipsla_id}	N/A	N/A	Created API to delete the IP-SLA with the given ID.
GET	... rest/v2/ip-slas/{IpSlaConfig.ipsla_id}/status	N/A	N/A	Created API to get the status of the IP-SLA matching with the given ID.
PUT	...rest/v2/ip-slas/{IpSlaConfig.ipsla_id}/status			

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	... rest/v2/ip-slas/history/{IpSlaHistory.ipsla_id}	N/A	N/A	API to update the IP-SLA status matching with the given ID.
GET	rest/v2/ip-slas/stats/{IpSlaMessageStats.ipsla_id}	N/A	N/A	Created API to get the details of IP-SLA history matching with the given ID.
POST	rest/v2/ip-slas/{IpSlaConfig.ipsla_id}/clearstats	N/A	N/A	Created API to get the details of IP-SLA stats matching with the given ID.
GET	rest/v2/ip-slas/jitter-voip/results/{IpSlaJitterVoipResults.ipsla_id}	N/A	N/A	API to clear history and message statistics of IP-SLA based on IP-SLA ID.
GET	rest/v2/ip-slas/jitter-voip/aggregated_results/{IpSlaJitterVoipResults.ipsla_id}	N/A	N/A	Created API to get the status of the IP-SLA results matching with the given ID.
GET	rest/v2/ip-slas/jitter-voip/aggregated_results/{IpSlaJitterVoipResults.ipsla_id}	N/A	N/A	Created API to get the status of the IP-SLA aggregated results matching with the given ID.

Service IpSlaResponder

HTTP Method	Resource	Request	Response	Description
GET	.../ipsla_responders			
		N/A	WiredElementList	Returns IP SLA Responder List.

Table Continued

HTTP Method	Resource	Request	Response	Description
POST	.../ipsla_responders	IpSlaResponder	IpSlaResponder	Adds the given IP SLA responder to the model.
GET	.../ipsla_responders/{IpSlaResponder.responder_type}- {IpSlaResponder.destination_address}-{ IpSlaResponder.destination_port}- {IpSlaResponder.source_address}	N/A	IpSlaResponder	Returns the IP SLA responder by responder details.
DELETE	.../ipsla_responders/{IpSlaResponder.responder_type}- {IpSlaResponder.destination_address}-{ IpSlaResponder.destination_port}- {IpSlaResponder.source_address}	N/A	N/A	Deletes IP SLA responder by responder details.

Service IpSlaResponderStats

HTTP Method	Resource	Request	Response	Description
GET	.../ipslas_responders/statistics/{IpSlaResponderStats.responder_type}- { IpSlaResponderStats.destination_address}-{ IpSlaResponderStats.destination_port}- { IpSlaResponderStats.source_address}	N/A	IpSlaResponderStats	Returns the IP SLA responder statistics by responder details.

Service LACP

HTTP Method	Resource	Request	Response	Description
GET	.../lACP/port	N/A	WiredElementList	Returns the list port trunk configurations
POST	.../lACP/port	LACP	LACP	Adds port to a LACP Trunk.
GET	.../lACP/port/{LACP.port_id}			

Table Continued

HTTP Method	Resource	Request	Response	Description
		N/A	Lacp	Returns the LACP Port Configuration.
DELETE	.../lacp/port/{Lacp.port_id}	N/A	Void	Deletes Port From a LACP trunk.

Service LocatorLedBlink

HTTP Method	Resource	Request	Response	Description
POST	.../locator-led-blink			
		N/A	N/A	Triggers a locator led blink based on the given parameters.



New attributes “when” and “member_id” are added in `LocatorLedBlinkCommand.json` (request).

Service MacAuthenticationPort

HTTP Method	Resource	Request	Response	Description
GET	.../mac-authentication/port			
		N/A	WiredElementList	Returns the list of MAC Authentication Port elements matching the given query.
GET	.../mac-authentication/port/{MacAuthenticationPort.port_id}			
		N/A	MacAuthenticationPort	Returns the MAC Authentication Port matching the given ID.
PUT	.../mac-authentication/port/{MacAuthenticationPort.port_id}			
		N/A	MacAuthenticationPort	Updates the given MAC Authentication Port in the model.

Service MacAuthentication

HTTP Method	Resource	Request	Response	Description
GET	.../mac-authentication			
		N/A	MacAuthentication	Returns the global MAC authentication configuration.
PUT	.../mac-authentication			
		MacAuthentication	MacAuthentication	Updates the global MAC authentication configuration.

Service MacTable

HTTP Method	Resource	Request	Response	Description
GET	.../mac-table			
		N/A	WiredElementList	Returns a list of MAC entries (capped to 1K right now).
GET	.../mac-table/{MacAddress.octets}			
		N/A	MacTableEntry	Returns the MAC table entry for the given MAC address.
GET	.../ports/{Port.id}/mac-table			
		N/A	WiredElementList	Returns list of MAC entries learned on a given Port ID.
GET	.../vlans/{Vlan.vlan_id}/mac-table			
		N/A	WiredElementList	Returns list of MAC entries learned on a given VLAN ID.

Service Module

HTTP Method	Resource	Request	Response	Description
GET	.../mstp			
		N/A	Mstp	Returns the global MSTP settings.

Service Mstp

HTTP Method	Resource	Request	Response	Description
GET	.../mstp			
		N/A	Mstp	Returns the global MSTP settings.
PUT	.../mstp	Mstp	Mstp	Updates the global MSTP settings.
GET	.../mstp/port			
		N/A	WiredElementList	Returns the list of MSTP Port elements matching the given query.
GET	.../mstp/port/{ MstpPort .id}			
		N/A	MstpPort	Returns the MSTP Port matching the given ID.
PUT	.../mstp/port/{ MstpPort .id}	MstpPort	MstpPort	Updates the MSTP Port matching the given ID.

Service Oobm

HTTP Method	Resource	Request	Response	Description
GET	.../oobm			
		N/A	Oobm	Returns the OOBM settings.

Table Continued

HTTP Method	Resource	Request	Response	Description
PUT	.../oobm	Oobm	Oobm	Updates the OOBM settings.
GET	.../oobm/interface	N/A	OobmInterface	Returns the OOBM Interface settings.
PUT	.../oobm/interface	OobmInterface	OobmInterface	Updates the OOBM Interface settings.
GET	.../oobm/interface/stats	N/A	OobmInterfaceStats	Returns the OOBM Interface stats.

Service Poe

HTTP Method	Resource	Request	Response	Description
GET	.../system/status/power/consumption	N/A	WiredElementList	Returns the Power-Consumption status of the host system (no sampling info).



Applicable only for ArubaOS-Switch 5400R.

Service PortMirrorSession

HTTP Method	Resource	Request	Response	Description
GET	.../port-mirror	N/A	WiredElementList	Returns the list of Port Mirror Session elements matching the given query.
POST	.../port-mirror			

Table Continued

HTTP Method	Resource	Request	Response	Description
		PortMirrorSession	PortMirrorSession	Adds the given Port Mirror Session to the model.
GET	.../port-mirror/PortMirrorSession.session_id}			
		N/A	PortMirrorSession	Returns the Port Mirror Session matching the given ID.
PUT	.../port-mirror/{PortMirrorSession.session_id}			
		PortMirrorSession	PortMirrorSession	Updates the given Port Mirror Session in the model.
DELETE	.../port-mirror/{PortMirrorSession.session_id}			
		N/A	N/A	Deletes the Port Mirror Session with the given ID from the model.

Service PortRateLimit

HTTP Method	Resource	Request	Response	Description
GET	.../ports/rate_limit			
		WiredCollectionQuery	WiredElementList	Returns rate limit configurations for all ports and all traffic types.
GET	.../ports/rate_limit/{PortRateLimit.port_id}-{PortRateLimit.traffic_type}-{PortRateLimit.direction}			
		N/A	PortRateLimit	Returns port rate limit per port id, traffic type, and direction.
PUT	.../ports/rate_limit/{PortRateLimit.port_id}-{PortRateLimit.traffic_type}-{PortRateLimit.direction}			
		PortRateLimit	PortRateLimit	Updates attributes of port rate limit per port id, traffic type, and direction.

Service PortSecurity

HTTP Method	Resource	Request	Response	Description
GET	.../intrusion_logs			
		N/A	WiredElementList	Returns the intrusion logs
GET	.../portsec_policies			
		N/A	WiredElementList	Returns the list of Port Security elements matching the given query.
GET	.../portsec_policies/{PortSecurityPolicy .port_id}			
		N/A	PortSecurityPolicy	Returns the Port Security matching the given ID.
PUT	.../portsec_policies/{PortSecurityPolicy .port_id}			
		PortSecurityPolicy	PortSecurityPolicy	Updates the given Port Security in the model.

Service QosPort

HTTP Method	Resource	Request	Response	Description
GET	.../qos/ports-policies			
		WiredCollectionQuery	WiredElementList	Returns the list of QoS Port Policy elements matching the given query.
POST	.../qos/ports-policies			
		QosPortPolicy	QosPortPolicy	Adds the given QoS Port Policy to the model.
DELETE	.../qos/ports-policies/{QosPortPolicy.port_id}-{QosPortPolicy.policy_id}			

Table Continued

HTTP Method	Resource	Request	Response	Description
		N/A	N/A	Deletes the QoS Port Policy with the given ID from the model.
GET	.../qos/ports-policies/arg	N/A	N/A	Returns the QoS statistics for given policy and Port.

Service QoS Vlan

HTTP Method	Resource	Request	Response	Description
GET	.../qos/vlans-policies			
		WiredCollectionQuery	WiredElementList	Returns the list of QoS VLAN Policy elements matching the given query.
POST	.../qos/vlans-policies	QoS Vlan Policy	QoS Vlan Policy	Adds the given QoS VLAN Policy to the model.
DELETE	.../qos/vlans-policies/{QoS Vlan Policy.vlan_id}-{QoS Vlan Policy.policy_id}	N/A	N/A	Deletes the QoS VLAN Policy with the given ID from the model.
GET	.../qos/vlans-policies/{QoS Vlan Policy.vlan_id}-{QoS Vlan Policy.policy_id}/stats	N/A	QoS Vlan Policy Stats	Returns the QoS statistics for given policy and VLAN.

Service RadiusServerGroup

HTTP Method	Resource	Request	Response	Description
POST	../radius/server_group			
		RadiusServerGroup	RadiusServerGroup	Adds the given RADIUS server group to the model.
GET	../radius/server_group/{RadiusServerGroup.server_group_name}	N/A	RadiusServerGroup	Returns the RADIUS server_group pool by name.
DELETE	../radius/server_group/{RadiusServerGroup.server_group_name}	N/A	Void	Deletes RADIUS server group by name.

Service RedundancyManagement

HTTP Method	Resource	Request	Response	Description
GET	../redundancy-management/stats			
		N/A	N/A	Returns the Redundancy Management stats.



New attributes, "member_id", "member_description" and "member_state" are added in RedundancyManagementStatsEntry.json (in response).

Service RestVersion

HTTP Method	Resource	Request	Response	Description
GET	../version			
		N/A	WiredElementList	Returns the REST Version details.

Service Snmpv3

HTTP Method	Resource	Request	Response	Description
GET	.../snmpv3	N/A	SnmpV3	Returns the Snmpv3Server.
PUT	.../snmpv3	SnmpV3	SnmpV3	Updates the Snmpv3Server.
GET	.../snmpv3/users	N/A	WiredElementList	Returns all the Snmpv3Users.
POST	... /snmpv3/users	SnmpV3	SnmpV3User	Adds the given Snmpv3User.
GET	... /snmpv3/users/{SnmpV3User .user_name}	N/A	SnmpV3User	Returns the specified Snmpv3User.
PUT	... /snmpv3/users/{SnmpV3User .user_name}	SnmpV3	SnmpV3User	Updates the given Snmpv3User.
DELETE	... /snmpv3/users/{SnmpV3User .user_name}	N/A	N/A	Deletes the given Snmpv3User.
GET	... /snmpv3/notify_names	N/A	WiredElementList	Returns all the Snmpv3Notify entries.
POST	... /snmpv3/notify_names			

Table Continued

HTTP Method	Resource	Request	Response	Description
		SnmpV3NotifyName	SnmpV3NotifyName	Adds the given Snmpv3Notify entry.
GET	... /snmpv3/notify_names/{SnmpV3NotifyName .notify_name}	N/A	SnmpV3NotifyName	Returns the specified Snmpv3Notify entry.
DELETE	.../snmpv3/notify_names/{SnmpV3NotifyName .notify_name}	N/A	N/A	Deletes the given Snmpv3Notify entry.
GET	... /snmpv3/params	N/A	WiredElementList	Returns all the Snmpv3Params entries.
POST	... /snmpv3/params	SnmpV3Param	SnmpV3Param	Adds the given Snmpv3Param entry.
GET	... /snmpv3/params/{SnmpV3Param .parameter_name}	N/A	SnmpV3Param	Returns the specified Snmpv3Param entry.
PUT	... /snmpv3/params/{SnmpV3Param .parameter_name}	SnmpV3Param	SnmpV3Param	Updates the given Snmpv3Param entry.
DELETE	... /snmpv3/params/{SnmpV3Param.parameter_name}	N/A	N/A	Deletes the given Snmpv3Param entry.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	... /snmpv3/target_addresses	N/A	WiredElementList	Returns all the Snmpv3Target Addresses entries.
POST	... /snmpv3/target_addresses	SnmpV3TargetAddress	SnmpV3TargetAddress	Adds the given Snmpv3Target Address entry.
GET	... /snmpv3/target_addresses/{SnmpV3TargetAddress .target_address_name}	N/A	SnmpV3TargetAddress	Returns the specified Snmpv3Target Address entry.
PUT	... /snmpv3/target_addresses/{SnmpV3TargetAddress .target_address_name}	SnmpV3TargetAddress	SnmpV3TargetAddress	Updates the given Snmpv3Target Address entry.
DELETE	... /snmpv3/target_addresses/{SnmpV3TargetAddress .target_address_name}	N/A	N/A	Deletes the given Snmpv3Target Address entry.

Service SnmpServer

HTTP Method	Resource	Request	Response	Description
GET	.../snmp-server	N/A	SnmpServer	Returns properties of SNMP-Server.
PUT	.../snmp-server	SnmpServer	SnmpServer	Updates properties of SNMP-Server in the model.

Service SnmpServerCommunities

HTTP Method	Resource	Request	Response	Description
GET	.../snmp-server/communities			
		N/A	WiredElementList	Returns the SNMP-Server Community list.
POST	.../snmp-server/communities			
		SnmpServerCommunity	SnmpServerCommunity	Adds SNMP-Server Communities in the model.
GET	.../snmp-server/communities/{SnmpServerCommunity .community_name}			
		N/A	SnmpServerCommunity	Returns the SNMP-Server Community by name.
PUT	.../snmp-server/communities/{SnmpServerCommunity .community_name}			
		N/A	SnmpServerCommunity	Updates the SNMP-Server Community by name.
DELETE	.../snmp-server/communities/{SnmpServerCommunity .community_name}			
		N/A	N/A	Deletes the SNMP-Server Community by name.

Service SnmpServerHosts

HTTP Method	Resource	Request	Response	Description
GET	.../snmp-server/hosts			
		N/A	WiredElementList	Returns the SNMP-Server Host details.
POST	.../snmp-server/hosts			
		SnmpServerHost	SnmpServerHost	Adds SNMP-Server Hosts in the model.
GET	.../snmp-server/hosts/{ SnmpServerHost.host_ip}-{SnmpServerHost .community}			

Table Continued

HTTP Method	Resource	Request	Response	Description
		N/A	SnmpServerHost	Returns the SNMP-Server Host by name.
PUT	.../snmp-server/hosts/{ SnmpServerHost.host_ip}-{SnmpServerHost .community}			
		SnmpServerHost	SnmpServerHost	Updates SNMP-Server Host in the model.
DELETE	.../snmp-server/hosts/{ SnmpServerHost.host_ip}-{SnmpServerHost .community}			
		N/A	N/A	Deletes the SNMP-Server Host by name.

Service SnmpServerMib

HTTP Method	Resource	Request	Response	Description
GET	.../snmp-server/mib			
		N/A	SnmpServerMib	Returns SNMP-Server MIB settings.
PUT	.../snmp-server/mib			
		SnmpServerMib	SnmpServerMib	Updates SNMP-Server MIB settings in the model.

Service SnmpServerResponseSource

HTTP Method	Resource	Request	Response	Description
GET	.../snmp-server/response-source			
		N/A	SnmpServerResponseSource	Returns the SNMP-Server Response Source details.
PUT	.../snmp-server/response-source			
		SnmpServerResponseSource	SnmpServerResponseSource	Updates SNMP-Server Response Source in the model.

Service SnmpServerTraps

HTTP Method	Resource	Request	Response	Description
GET	../snmp-server/traps			
		N/A	SnmpServerTraps	Returns the SNMP-Server Traps.
PUT	../snmp-server/traps			
		SnmpServerTraps	SnmpServerTraps	Updates the SNMP-Server Traps in the model.
GET	../snmp-server/traps/linktraps			
		N/A	WiredElementList	Returns the SNMP-Server Link Change Traps.
GET	../snmp-server/traps/linktraps/{ SnmpServerLinkChangeTrap.port_id}			
		N/A	SnmpServerLinkChangeTrap	Returns the SNMP-Server Link Traps for specified port.
PUT	../snmp-server/traps/linktraps/{SnmpServerLinkChangeTrap.port_id}			
		SnmpServerLinkChangeTrap	SnmpServerLinkChangeTrap	Updates the SNMP-Server Link Traps for specified port in the model.

Service SnmpServerTrapSource

HTTP Method	Resource	Request	Response	Description
GET	../snmp-server/trap-source			
		N/A	SnmpServerTrapSource	Returns the SNMP-Server Trap Source details.
PUT	../snmp-server/trap-source			
		SnmpServerTrapSource	SnmpServerTrapSource	Updates SNMP-Server Trap Source in the model.

Service SpanningTree

HTTP Method	Resource	Request	Response	Description
GET	.../stp			
		N/A	SpanningTree	Returns Spanning Tree global configuration.
POST	.../stp			
		SpanningTree	SpanningTree	Updates attributes of SpanningTree.
GET	.../stp/ports			
		WiredCollectionQuery	WiredElementList	Returns Spanning Tree configuration for all ports.
GET	.../stp/ports/{SpanningTreePort.port_id}			
		N/A	SpanningTreePort	Returns Spanning Tree per port configuration.
GET	.../stp/ports/{SpanningTreePort.port_id}			
		SpanningTreePort	SpanningTreePort	Updates attributes of SpanningTree per port.



Supports RapidPVST.

Service SwitchConfig

HTTP Method	Resource	Request	Response	Description
GET	../switch-config			
		N/A	SwitchConfig	Returns the config.
POST	../switch-config			

Table Continued

HTTP Method	Resource	Request	Response	Description
		SwitchConfigCmd	SwitchConfigCmdResult	Updates the given config to the model.
GET	./switch-config/status			
		N/A	SwitchConfigStatus	Returns the config upload status.

Service SwitchSystem

HTTP Method	Resource	Request	Response	Description
GET	.../system/status/switch			
		N/A	SwitchSystemInfoStats	Returns the status of the ArubaOS-Switch system.

Service Syslog

HTTP Method	Resource	Request	Response	Description
GET	.../syslog			
		N/A	Syslog	Returns the syslog details.
PUT	.../syslog			
		Syslog	Syslog	Adds the given syslog configurations.

Service SyslogEventCriteria

HTTP Method	Resource	Request	Response	Description
GET	.../syslog/filters/{filter_name}/event-criterias			
		N/A	WiredElementList	Returns the syslog filter criteria details.
POST	.../syslog/filters/{filter_name}/event-criterias			

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../syslog/filters/{filter_name}/event-criterias/{criteria_id}	SyslogEventCriteria	SyslogEventCriteria	Adds the given syslog filter criteria configurations.
PUT	.../syslog/filters/{filter_name}/event-criterias/{criteria_id}	N/A	SyslogEventCriteria	Returns the syslog filter criteria details by Criteria id.
DELETE	.../syslog/filters/{filter_name}/event-criterias/{criteria_id}	SyslogEventCriteria	SyslogEventCriteria	Update the Syslog EventCriteria Configurations by criteria id .
DELETE	.../syslog/filters/{filter_name}/event-criterias/{criteria_id}	N/A	Void	Deletes the Syslog EventCriteria Configurations by criteria_id .

Service SyslogFilter

HTTP Method	Resource	Request	Response	Description
GET	.../syslog/filters	N/A	WiredElementList	Returns the syslog filter details.
POST	.../syslog/filters	SyslogFilter	SyslogFilter	Adds the given syslog configurations.
GET	.../syslog/filters/{filter_name}	N/A	SyslogFilter	Get the Syslog Filter Configurations by filter name.
PUT	.../syslog/filters/{filter_name}	SyslogFilter	SyslogFilter	Update the Syslog Filter Configurations by filter name.

Table Continued

HTTP Method	Resource	Request	Response	Description
DELETE	.../syslog/filters/{filter_name}	N/A	Void	Deletes the Syslog Filter Configurations by filter name.

Service TACACSPROFILE

HTTP Method	Resource	Request	Response	Description
GET	.../tacacs_profile	N/A	TacacsProfile	Returns TACACS Profile.
PUT	.../tacacs_profile	TacacsProfile	TacacsProfile	Updates attributes of TACACS

Service TAConfig

HTTP Method	Resource	Request	Response	Description
GET	.../ta_profiles	N/A	WiredElementList	Returns the list of TA Profiles matching the given query.
POST	.../ta_profiles	TaProfile	TaProfile	Adds the given TA profile to the system.
GET	.../ta_profiles/{TaProfile.ta_name}	N/A	TaProfile	Returns the TA profile configuration matching the given profile name.
PUT	.../ta_profiles/{TaProfile.ta_name}	TaProfile	TaProfile	Updates the TA Profile Configuration matching the given profile name.

Table Continued

HTTP Method	Resource	Request	Response	Description
DELETE	.../ta_profiles/{TaProfile.ta_name}	N/A	N/A	Deletes the TA profile Configuration with the given profile name from the model.

Service TftpClient

HTTP Method	Resource	Request	Response	Description
GET	.../tftp/client	N/A	TftpClient	Returns TFTP Client system attributes.
PUT	.../tftp/client	TftpClient	TftpClient	Updates TFTP Client system attributes.

Service Transceiver

HTTP Method	Resource	Request	Response	Description
GET	.../transceivers	N/A	WiredElementList	Returns the list of Transceiver elements matching the given query.
GET	.../transceivers/{Transceiver.serial_number}	N/A	Transceiver	Returns the Transceiver matching the given ID.
GET	.../transceivers/{Transceiver.serial_number}/diagnostics	N/A	TransceiverDiagnostics	Returns the Transceiver Diagnostics matching the given ID.

Service Trunk

HTTP Method	Resource	Request	Response	Description
GET	.../trunk/port			
		N/A	WiredElementList	Returns the list port trunk configurations.
POST	.../trunk/port			
		Trunk	Trunk	Adds port to a Static Manual Trunk.
GET	.../trunk/port/{Trunk.port_id}			
		N/A	Trunk	Returns the TRUNK Port Configuration.
DELETE	.../trunk/port/{Trunk.port_id}			
		N/A	Void	Deletes Port From a Trunk.

Service VsfCommand

HTTP Method	Resource	Request	Response	Description
POST	.../stacking/vsf/disable			
		N/A	N/A	Disable VSF stack.
POST	.../stacking/vsf/enable			
		VsfEnableCommand	N/A	Enable and Modify domain of VSF stack.
POST	.../stacking/vsf/member/remove			
		VsfRemoveMemberCommand	N/A	Removes the member specified by member id and reboots the member if reboot is true.

Table Continued

HTTP Method	Resource	Request	Response	Description
POST	.../stacking/vsf/member/shutdown	VsfMemberShutdownCommand	N/A	Shut down the member specified by member id.

Service VsfConfig

HTTP Method	Resource	Request	Response	Description
GET	.../stacking/vsf/global_config	N/A	VsfGlobalConfig	Returns the VSF Global Configuration.
PUT	.../stacking/vsf/global_config	VsfGlobalConfig	VsfGlobalConfig	Updates the VSF Global Configuration.
GET	.../stacking/vsf/info	N/A	VsfStackInfo	Returns the VSF stack Information.
GET	.../stacking/vsf/led_locator_info	N/A	WiredElementList	Returns the LED Locator Configuration.
GET	.../stacking/vsf/led_locator_info/{LocatorLedResult.member_id}	N/A	LocatorLedResult	Returns the LED Locator Configuration.
GET	.../stacking/vsf/members	N/A	WiredElementList	Returns the list of VSF Members matching the given query.
POST	.../stacking/vsf/members	VsfMember	VsfMember	Adds the given VSF Member to the system.

Table Continued

HTTP Method	Resource	Request	Response	Description
GET	.../stacking/vsf/members/{VsfMember .member_id}	N/A	VsfMember	Returns the VSF Member Configuration matching the given ID.
PUT	.../stacking/vsf/members/{VsfMember.member_id}	VsfMember	VsfMember	Updates the VSF Member Configuration matching the given ID.
GET	.../stacking/vsf/members/{member_id}/links	N/A	WiredElementList	Returns the list of VSF Links matching the given query.
POST	.../stacking/vsf/members/{VsfLink .member_id}/links	VsfLink	VsfLink	Adds the given VSF Link to the system.
GET	.../stacking/vsf/members/{ VsfLink .member_id}/links/{ VsfLink.link_id}	N/A	VsfLink	Returns the VSF Link Configuration matching the given ID.
PUT	.../stacking/vsf/members/{VsfLink.member_id}/links/{VsfLink.link_id}	VsfLink	VsfLink	Updates the VSF Link Configuration matching the given ID.
DELETE	.../stacking/vsf/members/{VsfLink .member_id}/links/{VsfLink .link_id}	N/A	Void	Deletes the VSF Link with the given ID from the model.
GET	.../stacking/vsf/members/{member_id}/links/{link_id}/ports	N/A	WiredElementList	Returns the list of VSF Ports matching the given query.
POST	.../stacking/vsf/members/{VsfPort.member_id}/links/{VsfPort.link_id}/ports			

Table Continued

HTTP Method	Resource	Request	Response	Description
		VsfPort	VsfPort	Adds the given VSF Port to the link.
DELETE	.../stacking/vsf/members/{ VsfPort.member_id}/links/{VsfPort.link_id}/ports/{VsfPort.port_id}			
		N/A	Void	Deletes the VSF Port from the link.
GET	.../stacking/vsf/members/system_info			
		N/A	WiredElementList	Returns the list of VSF Member Information matching the given query.
GET	.../stacking/vsf/members/system_info/{VsfMemberSystemInfo.member_id}			
		N/A	VsfMemberSystemInfo	Returns the VSF Member Information matching the given ID.
GET	.../stacking/vsf/members_links_ports			
		N/A	VsfMembersLinksPorts	Returns the list of VSF Members-Links-Ports Associations in the system.

Service WebAuth

HTTP Method	Resource	Request	Response	Description
GET	.../webauth			
		N/A	WebAuth	Returns the global WEB Auth configuration.
PUT	.../webauth			
		WebAuth	WebAuth	Updates the global WEB Auth configuration.

Service WebAuthPort

HTTP Method	Resource	Request	Response	Description
GET	.../webauth/port			
		N/A	WiredElementList	Returns the list of WEB Auth Port elements matching the given query.
GET	.../webauth/port/{WebAuthPort.port_id}			
		N/A	WebAuthPort	Returns the WEB Auth Port matching the given ID.
PUT	.../webauth/port/{WebAuthPort.port_id}			
		WebAuthPort	WebAuthPort	Updates the given WEB Auth Port in the model.

Networking Websites

Hewlett Packard Enterprise Networking Information Library

www.hpe.com/networking/resourcefinder

Hewlett Packard Enterprise Networking Software

www.hpe.com/networking/software

Hewlett Packard Enterprise Networking website

www.hpe.com/info/networking

Hewlett Packard Enterprise My Networking website

www.hpe.com/networking/support

Hewlett Packard Enterprise My Networking Portal

www.hpe.com/networking/mynetworking

Hewlett Packard Enterprise Networking Warranty

www.hpe.com/networking/warranty

General websites

Hewlett Packard Enterprise Information Library

www.hpe.com/info/EIL

For additional websites, see **[Support and other resources](#)**.

Accessing Hewlett Packard Enterprise Support

- For live assistance, go to the Contact Hewlett Packard Enterprise Worldwide website:
<http://www.hpe.com/assistance>
- To access documentation and support services, go to the Hewlett Packard Enterprise Support Center website:
<http://www.hpe.com/support/hpesc>

Information to collect

- Technical support registration number (if applicable)
- Product name, model or version, and serial number
- Operating system name and version
- Firmware version
- Error messages
- Product-specific reports and logs
- Add-on products or components
- Third-party products or components

Accessing updates

- Some software products provide a mechanism for accessing software updates through the product interface. Review your product documentation to identify the recommended software update method.
- To download product updates:

Hewlett Packard Enterprise Support Center

www.hpe.com/support/hpesc

Hewlett Packard Enterprise Support Center: Software downloads

www.hpe.com/support/downloads

Software Depot

www.hpe.com/support/softwaredepot

- To subscribe to eNewsletters and alerts:
www.hpe.com/support/e-updates
- To view and update your entitlements, and to link your contracts and warranties with your profile, go to the Hewlett Packard Enterprise Support Center **More Information on Access to Support Materials** page:
www.hpe.com/support/AccessToSupportMaterials



Access to some updates might require product entitlement when accessed through the Hewlett Packard Enterprise Support Center. You must have an HPE Passport set up with relevant entitlements.

Customer self repair

Hewlett Packard Enterprise customer self repair (CSR) programs allow you to repair your product. If a CSR part needs to be replaced, it will be shipped directly to you so that you can install it at your convenience. Some parts

do not qualify for CSR. Your Hewlett Packard Enterprise authorized service provider will determine whether a repair can be accomplished by CSR.

For more information about CSR, contact your local service provider or go to the CSR website:

<http://www.hpe.com/support/selfrepair>

Remote support

Remote support is available with supported devices as part of your warranty or contractual support agreement. It provides intelligent event diagnosis, and automatic, secure submission of hardware event notifications to Hewlett Packard Enterprise, which will initiate a fast and accurate resolution based on your product's service level. Hewlett Packard Enterprise strongly recommends that you register your device for remote support.

If your product includes additional remote support details, use search to locate that information.

Remote support and Proactive Care information

HPE Get Connected

www.hpe.com/services/getconnected

HPE Proactive Care services

www.hpe.com/services/proactivecare

HPE Proactive Care service: Supported products list

www.hpe.com/services/proactivecaresupportedproducts

HPE Proactive Care advanced service: Supported products list

www.hpe.com/services/proactivecareadvancedsupportedproducts

Proactive Care customer information

Proactive Care central

www.hpe.com/services/proactivecarecentral

Proactive Care service activation

www.hpe.com/services/proactivecarecentralgetstarted

Warranty information

To view the warranty for your product or to view the *Safety and Compliance Information for Server, Storage, Power, Networking, and Rack Products* reference document, go to the Enterprise Safety and Compliance website:

www.hpe.com/support/Safety-Compliance-EnterpriseProducts

Additional warranty information

HPE ProLiant and x86 Servers and Options

www.hpe.com/support/ProLiantServers-Warranties

HPE Enterprise Servers

www.hpe.com/support/EnterpriseServers-Warranties

HPE Storage Products

www.hpe.com/support/Storage-Warranties

HPE Networking Products

www.hpe.com/support/Networking-Warranties

Regulatory information

To view the regulatory information for your product, view the *Safety and Compliance Information for Server, Storage, Power, Networking, and Rack Products*, available at the Hewlett Packard Enterprise Support Center:

www.hpe.com/support/Safety-Compliance-EnterpriseProducts

Additional regulatory information

Hewlett Packard Enterprise is committed to providing our customers with information about the chemical substances in our products as needed to comply with legal requirements such as REACH (Regulation EC No 1907/2006 of the European Parliament and the Council). A chemical information report for this product can be found at:

www.hpe.com/info/reach

For Hewlett Packard Enterprise product environmental and safety information and compliance data, including RoHS and REACH, see:

www.hpe.com/info/ecodata

For Hewlett Packard Enterprise environmental information, including company programs, product recycling, and energy efficiency, see:

www.hpe.com/info/environment

Documentation feedback

Hewlett Packard Enterprise is committed to providing documentation that meets your needs. To help us improve the documentation, send any errors, suggestions, or comments to Documentation Feedback (**docsfeedback@hpe.com**). When submitting your feedback, include the document title, part number, edition, and publication date located on the front cover of the document. For online help content, include the product name, product version, help edition, and publication date located on the legal notices page.